

DEPLOYMENT INSTRUCTIONS
WOCE-SVP DRIFTING BUOY

- 1) Remove the buoys from the shipping box.
- 2) **REMOVE ONLY** the plastic shrink-wrap. **DO NOT REMOVE** paper tape securing the drogue and tether.



- 3) Record the six digit ID number. It can be found on the shipping container, the other side of this sheet or the outside of the buoy
- 4) If desired, the magnet can be removed to activate the buoy for testing. It is attached to the underside of the float with paper tape.
- 5) The float/drogue assembly should then be lowered or heaved into the water away from any obstructions (such as the side of the vessel) and from a position as near to the stern as possible.
- 6) Record the date, time (GMT) and location of deployment as well as the six digit ID, and send this information to the Global Drifter Program.

(Shaun R. Dolk, Shaun.Dolk@noaa.gov)

Sample log sheet

ID	Date	Time (GMT)	Latitude	Longitude
xxxxx	mm/dd/yy	hh:mm	DD mm.mm NS	DDD mm.mm EW
<u>129318</u>	<u>06, 28, 15</u>	<u>11:55</u>	<u>59 00 S</u>	<u>63 43 W</u>